

## WATTS 007

### 007 1ST OR 2ND CHECK COMPLETE 1 ONLY

0887193	007 AUS	15mm
0887026	007 M1	20-25mm

### 007 1ST CHECK COMPLETE

0887045	007 M2	20mm
0888550	007 M3	20mm
0887023	007 AUS 2	0-25mm
0887025	007 AUS	40-50mm
0887186	007 M1	40-50mm
0887719	007 M2	32-40mm
0887285	007	65-80mm

### 007 2ND CHECK COMPLETE

0887046	007 M2	20mm
0888551	007 M3	20mm
0887024	007 AUS	20-25mm
0887028	007 AUS	40-50mm
0887187	007 M1	40-50mm
0887720	007 M2	32-40mm
0887286	007	65-80mm

### 007 COMPLETE RUBBER PARTS

0887194	007 AUS	15mm
0887043	007 M2	20mm
0888552	007 M3	20mm
0887040	007 AUS	20-25mm
0887042	007 M1	20-25mm
0887041	007 AUS	40-50mm
0887188	007 M1	40-50mm
0887721	007 M2	32-40mm
0887287	007	65-80mm

### 007 SEAT KITS

0887289	007 AUS 1st check seat only	65-80mm
0887290	007 AUS 2nd check seat only	65-80mm

### 007 UNIVERSAL SPARES: CONTAINS ALL COMPLETE RUBBER PARTS KITS FOR SIZE OF VALVE:

0887800	007	20mm
0887801	007	25mm
0887802	007	40mm
0887803	007	50mm

### 007 RETAINERS

1047053	007 AUS	15mm
1047382	007 M1	20-25mm
1047394	007 M2/M3	20mm
1047001	007 AUS	40-50mm
1047112	007 M1	40-50mm
1047099	007 M2	32-40mm

### 007 TEST COCKS

0006630	007	15-25mm
0006635	007	32-50mm

## AMES 2000B

### 2000B 1ST CHECK COMPLETE

7016330	2000B	15mm
7016331	2000B M2	20mm
7016332	2000B M3	20mm
7016333	2000B M2	25mm
7016334	2000B M2	32-40mm
7016335	2000B M2	50mm

### 2000B 2ND CHECK COMPLETE

7016330	2000B	15mm
7016337	2000B M2	20mm
7016338	2000B M3	20mm
7016333	2000B M2	25mm
7016340	2000B M2	32-40mm
7016341	2000B M2	50mm

### 2000B COMPLETE RUBBER PARTS

7016348	2000B	15mm
7016349	2000B M2	20mm
7016350	2000B M3	20mm
7016351	2000B M2	25mm
7016352	2000B M2	32-40mm
7016353	2000B M2	50mm

### 2000B TEST COCKS

7017250	2000B	15-25mm
7017251	2000B	32-50mm WATTS 709 (DCV)